

RU инструкция по монтажу и эксплуатации душевых систем с термостатическим смесителем

PL instrukcja montażu i obsługi systemów prysznicowych z baterią termostatyczną

EN installation and operation manual for shower systems with thermostatic faucets

KK термостат араластығышы бар дүш жүйелеріне арналған монтаждай және експлуатация бойынша нұсқаулық

AZ termostatik su kranlı duş sistemlərinin quraşdırılması və istismarı üzrə təlimat

UZ termostatli smesiteli bor duş tizimini o'rnatish va foydalanish bo'yicha yo'riqnomasi

KG термостатикалык чабыштыргычы бар душ тутумун орнотуу жана иштетүү боюнча нускама

KA თერმოსტატული მუხრებიანი საშხაპე სისტემების მონტაჟის და ექსპლუატაციის ინსტრუქცია

TK termostatiki garyjivly duş ulgamlaryny gurnamak we ulanmak boýunça gözükdirme

HY սերմոստատային ծորակով ցնցողի համակարգի Տեղադրման և շահագործման Իրաւահաղ





TJ дастурал оид ба насбкунӣ ва истифодабарии системаҳои душӣ бо омехтақунандаи термостатикӣ

MN халуун хүйтэн тогтмол байлгах ус холигчтой шүршүүр систем угсрах ба ашиглах заавар




Ø 6 mm


2,5 mm




5




6




7



8







9





$38 \pm 2^\circ\text{C}$ OK → 12

$38 \pm 2^\circ\text{C}$ not OK → 10


10




11






12



13



A**H₂O + SOAP +** **B****C****D**